



**OPERATION OF THE MuTr TEST STAND GAS  
SYSTEM IN BLDG. 905**

procedure name

**PHENIX Procedure No. PP-2.5.2.12-02**

**Revision: A**

**Date: 6-22-99**

**Hand Processed Changes**

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

**Approvals**

11/11  
PHENIX S E & I    Date

*Paula Kowalski* <sup>X-7.309</sup> <sup>SAUG99</sup>  
Cognizant Scientist/Engineer    Date  
/Activity Manager

*William King* <sup>8/24/99</sup>  
PHENIX QA/Safety    Date

*John H.* <sup>8-29-99</sup>  
RHIC ES&H    Date

**REVISION CONTROL SHEET**

<b>LETTER</b>	<b>DESCRIPTION</b>	<b>DATE</b>	<b>WRITTEN BY</b>	<b>APPROVED BY</b>	<b>CURRENT OVERSIGHT</b>
A	First Issue	6/22/1999	n/a	R. Towell, W. Lenz, A. Etkin	n/a
RETIRED	Tests Completed	3/9/2007	n/a	D. Lynch, R. Pisani, P. Giannotti for PHENIX	D.Lynch

## 1.0 Purpose and Scope

This procedure provides instructions for the safe operation of the gas systems in the test stand area in building 905 that is used for Q/A testing of the MuTr cathode strip chambers. It describes the process to move a gas bottle, change or replace a gas bottle, and how to adjust the flow. It is intended for nonflammable gas mixtures only.

## 2.0 Responsibilities

- 2.1 Operator is responsible for conducting the procedures and logging of the gas operation in the logbook.
- 2.2 Operator is responsible for following all instructions in ESH 1.4.0 "Compressed Gas Cylinder Safety".

## 3.0 Prerequisites

- 3.1 Formal BNL compressed gas safety training.
- 3.2 Training must be documented on the worker's BNL training record.

## 4.0 Moving a gas bottle - general:

- 4.1 Adhere to all ESH 1.4.0 section VI.A instructions.

## 5.0 Removing empty bottle:

- 5.1 Close "Bottle Regulator Output" valve (V51-56) in line downstream of the bottle regulator. (valve handle horizontal is closed)
- 5.2 Close bottle valve on top of gas bottle. (turn valve clockwise to close)
- 5.3 Open "Bottle Regulator Purge" valve (V91-96). (valve handle vertical is open)
- 5.4 Verify that both the high and low pressure regulator gases go to zero.
- 5.5 Remove pigtail from bottle.
- 5.6 Install bottle safety cap.
- 5.7 Tear off "In Service" portion of tag on bottle so it now shows only EMPTY.
- 5.8 Move bottle to storage cage observing requirements in 4.0.

## 6.0 Installing full bottle:

- 6.1 Install bottle in rack and secure with strap.
- 6.2 Remove safety cap.
- 6.3 Clean bottle outlet port:
  - 6.3.1 SAFETY REQUIREMENTS:
    - 6.3.1.1 Operator MUST wear goggles, or safety glasses with side shields, to prevent getting dirt in their eyes.
    - 6.3.1.2 Opening the bottle valve to blow out the valve body with bottle pressure is NEVER permitted.
    - 6.3.1.3 Wearing a glove is a good way to reduce the risk of cutting a finger on sharp threads.
  - 6.3.2 Wipe threads with a clean rag.
  - 6.3.3 Blow out bottle valve with an air duster, while standing to the rear of the bottle valve.
- 6.4 Make sure that the "Bottle Regulator Purge" valve, V91-96, is still open.
- 6.5 Check cleanliness of the Pigtail.
- 6.6 Hook up the bottle to regulator pigtail and tighten with an open-end wrench of the correct size.  
Note: Non-flammable gas fittings are right hand threads
- 6.7 Open the bottle valve all the way and then close one half turn (to prevent the valve from sticking in the open position).

- 6.8 Close the "Bottle Regulator Purge" valve, V91-96, after 10 seconds of purging out the air that got into the open pigtail during the bottle change.
- 6.9 Perform leak checking (Use commercial leak checking fluid around bottle valve, neck, and head area.) Clean fluid residue after leak check.
- 6.10 Verify the "Bottle Regulator Purge" valve, V91-96, is still closed and the bottle regulator low-pressure gage reads about 10 psi.
- 6.11 Open "Bottle Regulator Output" valve, V51-56.
- 6.12 Document the bottle change on the log sheet.

## 7.0 Adjusting flow for chamber testing

- 7.1 Close valves V45 and V46 on the output side of the "Fixed Pressure Regulator" (R11-R12).
- 7.2 Insure both "Fixed Pressure Regulator" (R11 and R12) are set to 5 psig.
- 7.3 Open valves V45 and V46.
- 7.4 Ensure valves V61, V63, and V1 to V10 are still closed.
- 7.5 Determine correct flow for Argon and CO2 from calibration table. The correct ratio is 70% Argon and 30% CO2. The correct total flow is equal to the number of chambers under test and the number of chambers in the storage rack. For storage maintain a flow of 1 liter/min and for testing maintain a flow of 10 liter/min.
- 7.6 Ensure proper circuit block values (V21 to V30) are open.
- 7.7 Open fully needle valves (V71 to V80).
- 7.8 Adjust V43 and V44 to obtain proper mixture of Argon and CO2.
- 7.9 Adjust needle valves (V71 to V80) to get proper flow to each circuit.
- 7.10 Monitor the flow rates and bottle pressure daily and record in the logbook.

## 8.0 Attachments

- 8.1 List of gas system operators.
- 8.2 Diagram of the gas system.

## **Attachment 8.1: List of Gas System Operators**

1. DongJo Kim
2. Chris Kuberg
3. Dave Lee
4. Ray Savino
5. Bill Sandhoff
6. Matt Shaw
7. Makoto Sugioka
8. Rusty Towell
9. Christos Velissaris


NOTES:

8 7 6 5 4 3 2

REV	DATE	BY	CHKD	DESCRIPTION
1				

①	Flow Tube
②	Filter
③	Valve
④	Relief Valve
⑤	Gauge
⑥	Fixed Regulator
⑦	Flexible Line
⑧	Check Valve

Circuit 1-3-3-4-5-1 L/M  
Circuit 6-7-8-9-10-11 L/M



APPROVED FOR RELEASE	DATE	BY	CHKD	DESCRIPTION
1				